



EFP24 Frost Protector

Wiring diagram



Auto reset




Manual reset

1	Common contact
3	Close with temperature rising
5	Open with temperature falling

Note: † The action direction when temperature rises
 † M2 The direction for manual reset.

Mounting



Note: The factory sets a 2 metre length capillary.